

Optical Instruments for Environmental Monitoring

QSP-2000, Quantum Scalar Sensors Measuring Downwelling Irradiance over PAR(400-700nm)

Scalar PAR sensors in our new QSP-2000 series, feature Biospherical's patented spherical collector. This unique design ensures uniform directional response over 3.7 pi steradians. A stainless-steel encased, optical light-pipe funnels flux from the collector to a silicon photodetector that has a flat quantum response over PAR (Photosynthetically Active Radiation; 400 – 700 nm).

The most noteworthy improvement in this new series is the capability of direct connection to a PC or laptop computer. Our **QSP-2100** sensors contain imbedded calibration information and data are transmitted directly into the computer. This new low-power circuitry requires no batteries, relying instead upon power from the host computer's serial comport. Our new **QSP-2150** sensor output's an ASCII data stream, upon power-up.

QSP-2200 linear output models, feature high-quality, low-drift, electrometer-grade amplifiers and are are compatible with most commercially available dataloggers.

QSP-2300 and **QSP-2350**, logarithmic-output versions are also available. This sensor type is designed specifically for integration with CTD systems and dataloggers requiring a limited-range of signal input.



The new QSP-2000 is rugged and compact.

Key Features

 Designed to measure downwelling PAR (400-700 nm) irradiance to depths of 2000 meters

■ 1.9 cm (3/4") diameter solid Teflon® spherical irradiance collector

- Compact, rugged, and low-cost
- QSP-2100 includes operating software allowing direct connection to a PC, or laptop computer

Specifications

Optical Features

Scalar Irradiance Collector: 1.9 cm (3/4") diameter solid Teflon® sphere optically connected to the main housing by a 4.0 cm stainless-encased quartz light pipe.

Photodetector: Blue-enhanced, high-stability silicon detector with dichroic blocking filters.

PAR Spectral Response: Equal (better than $\pm 10\%$) quantum response from 400 nm to 700 nm with response sharply attenuated above 700 nm and below 400 nm. Spectral response-induced errors will cause less than 5% errors in naturally occurring light fields.

Directional Response: Each instrument's directional response is optimized before final calibration. Front-to-side (approximately 85° from head on) response over all angles is equal (± 6%). Individual detector response plots are available as an option.

Optical Features (Cont.)

Sensitivity: When purchased alone, the sensor is calibrated in quanta/(cm²·sec))/volt. Nominal sensitivity is 1 volt = 1×10^{17} quanta/(cm²·sec) (slightly less than full sunlight). Noise level is typically less than 1 millivolt, temperature coefficient of the dark signal is less than 10 microvolts/°C, and response temperature coefficient is less than 0.15%/°C.

Electronic Features Measured Signals:

PAR Dynamic Range: $1.4x10^{-5}$ $\mu E/(cm^2 \cdot sec)$ to $0.5 \ \mu E/(cm^2 \cdot sec)$

Environmental

Temperature Range: -2°C to 35°C

Fully calibrated with lamps traceable to NIST, each digital sensor contains imbedded calibration factors.

Calibration

Each QSP-2000 sensor is calibrated using a National Institute of Standards and Technology- (NIST) traceable 1000watt type FEL Standard of Spectral Irradiance using procedures recommended by NIST. Annual recalibration is strongly recommended.

Mechanical Features

Collector: Solid PTFE sphere, epoxy mounted to a machined aluminum base

Housing:

Hard-anodized aluminum, rated to 2000 meters

Dimensions:

Diameter: 5.0 cm *Height:* 15.0cm *Weight:* 1.1 kg





*Specifications subject to change without notice

BSI's new operating software, LOGGER-2100 logs and displays calibrated data in either Quanta or μEinsteins .

Biospherical Instruments Inc.

U.S. Patent No. 4,178,101

Biospherical Instruments Inc. 5340 Riley Street San Diego, CA 92110-2621 USA Phone: (619) 686-1888 Fax: (619) 686-1887 E-mail: sales@biospherical.com URL: www.biospherical.com

Copyright © Biospherical Instruments Inc., 2011